

DICKEY-JOHN®
HANDHELD MOISTURE TESTERS

GAC Mini 2500 Portable Grain Moisture Analyzer

The most accurate handheld moisture tester that provides fast and easy results. Now with 149 MHz – UGMA technology to match the new GAC2500UGMA moisture testers at the elevator (see page 2) for farmers that are conditioning their own grain and need the accuracy of a commercial meter at an affordable price. GACMINI2500 matches existing meter readings, but is completely portable, and Bluetooth enabled! Simply add the free app to your mobile device and test results are transmitted there (Bluetooth only available for USA, Canada, Japan, Hong Kong and European Union). The app allows you to record moisture, temperature, test weight, sample ID, date and time.

For farmers who have adapted precision farming into your operations, you can reliably and accurately pull moisture data from the GACMINI2500. This will allow you to use data from the mini to create accurate field maps, increase the accuracy of yield maps and track moisture field-by-field, year-over-year to evaluate moisture trends and field conditions. The GACMINI2500 will provide continuity from the field to the elevator by providing consistent results.

Unit can be programmed to read in English, Spanish, German, French, Italian, and Chinese.

The GACMINI2500 includes: tester, funnel, 9V battery, carrying case, belt clip, instruction manual and 1 year manufacturer’s warranty. Net wt: 3 lbs, Actual dims: 8.3" (L) x 4.8" (W) x 11.9" (H), Ship wt: 8 lbs, Ship dims: 19" (L) x 13" (W) x 8" (H).



GACMINI2500

Features and Benefits

- Simplifies operation with menu-driven interface
- Eliminates pre-weighing with an internal scale
- Avoids cumbersome screw caps that can damage grain and tests whole grains
- Measures over 250 types of grains and products
- Easily load calibrations with a USB or USB cable to your computer (cable included)
- Tests hot or cold grain between 32–122°F (0–50°C)
- Durable carrying and storage case with shoulder strap included

Hand Held Moisture Analyzer, 149 MHz with Bluetooth.....	No. GACMINI2500
Hand Held Moisture Analyzer, 149 MHz without Bluetooth.....	No. GACMINI2500NBT

GAC Mini and GAC Mini Plus Portable Grain Moisture Tester

The mini GAC® technology is based on the commercial and laboratory moisture tester Series GAC2100. This whole grain moisture tester includes an internal scale to eliminate pre-weighing and it has no screw caps to deal with. The moisture range is 5–45%, depending upon the grain type, a grain temperature range of 32–122°F (0–50°C). The sample size is approximately 1 pint and can hold 20 twenty-grain calibrations: Corn, Corn-High Moisture, Barley 6-Row, Barley 2-Row, Durum, Hard Red Winter Wheat, Hard Red Spring Wheat, Millet, Oats, Rapeseed, Rye, Safflower, Soft Red Winter Wheat, Sorghum, Soybeans, Sunflower Oil and four (4) empty calibrations, but the user can choose from over 450 calibrations. The tester can display in a choice of 16 languages including: English (US, UK, and AU), Spanish, French, Italian, German, Portuguese, Turkish, and other European languages (specify when ordering).

Available in two models, the Model GACMINI-P displays moisture percentage, temperature and approximate test weight readings. Each unit includes a 9V battery, carrying case, funnel assembly, belt clips, and instruction manual. The Model GACMINI-L displays moisture and temperature readings. The USB cable allows for the user to directly download alternate calibrations from the manufacturer website. Each unit includes a 9V battery and funnel assembly. Net wt: 2 lbs, 7 oz, Ship wt (with case): 8 lbs, Ship wt (without case): 7 lbs, Actual dims: 8.3" (L) x 4.8" (W) x 11.9" (H), Ship dims: 8" (L) x 12" (W) x 16" (H).



GACMINI-P

Hand Held Moisture Tester Plus Test Weight and Case....	No. GACMINI-P	Replacement Funnel Assembly.....	No. GACMINI-FUNNEL
Hand Held Moisture Tester without Case	No. GACMINI-L	USB Download Cable for GACMINI	No. GAC-CABLE
Carrying Case.....	No. GACMINI-CASE		