

Large Plot Thresher

The Almaco Large Plot Thresher is a versatile, high-capacity machine perfect for threshing large plots of Cereals, Forages, Legumes and Small Grains, Ship dims: 134" (L) x 82" (W) x 75" (H), Ship wt: 2650 lbs, Export dims: 122" (L) x 82" (W) x 75" (H), Export wt: 2750 lbs.



Standard Equipped:

- Overshot-style cylinder and concave with 14" diameter x 17⁵/₈", with your choice of cylinder type
- Variable speed v-belt drive for threshing cylinder, cylinder speed range 300–1500 RPM
- Adjustable enclosed overshot concave matched to threshing cylinder type
- Steel feeding table, hinged opposite operator
- Operators platform
- Metal shaker pan
- Centrifugal fan winnowing blower with control shutter
- Canvas deflector baffles
- Winnowing pan with adjustable angle
- Seed collecting chute with side exit opposite operator
- V-belt drives for low maintenance and quiet operation
- Safety guards
- Screw-type leveling jack and trailer hitch for 2" ball (50mm)
- Rubber cushion axle assembly, tapered roller bearings, 15" rims and radial tires
- Combination tail/stoptlights, turn signals, rear reflectors
- Strawpuller assembly

Selection Guide For Each Cylinder/Concave Style

Cylinder/Concave	Crops
Square-spiked tooth (most aggressive)	Cereals, Oats, Rice, Wheat, etc.
Round-spiked tooth	Sorghum, Soybeans
Metal raspbar	Grasses, Field Peas, Soybeans, Sunflower
Rubber-coated metal raspbar	Sorghum, Soybeans, Field Peas

Please select a Base Model and one each from: Power Configurations, Sieve Configurations, Threshing Cylinder and Concave Configurations, Machine Options and Accessories, and Domestic or Export Required Packing

Base Model	Power Configurations	Sieve Configurations	Threshing Cylinder and Concave Configurations	Machine Options and Accessories	Required Packing
No. SLPT	5HP, 220V/60Hz Electric Motor No. SLPT-A1	6mm Graepel Sieve (Grass) and Tailrake No. SLPT-C1	Rubber Raspbar No. SLPT-B1	Seed Catch Bucket No. SLPT-D1	Domestic Packing No. SLPT/DOM
	5HP, 220V/50Hz Electric Motor No. SLPT-A2	10mm Graepel Sieve for Small Seeded Crops and Tailrake No. SLPT-C2	Spiked Tooth No. SLPT-B2	Seed Tag Holder No. SLPT-D2	Export Packing Charges No. SLPT/EX
	8HP Honda Gas Engine with Elec. Start No. SLPT-A4	18mm Graepel Sieve and Tailrake No. SLPT-C3	Metal Raspbar No. SLPT-B3	Pneumatic Seed Delivery To Operator No. SLPT-D3	
	8HP Honda Gas Engine with Elec. Start with High Amp Charger No. SLPT-A5	20mm Graepel Sieve and Tailrake No. SLPT-C4	Metal Raspbar with Threshing Cylinder E-Brake No. SLPT-B4	Air Compressor with Horizontal Air Tank No. SLPT-D4	
	10HP Diesel Engine with Elec. Start No. SLPT-A7	22mm Graepel Sieve and Tailrake No. SLPT-C5		Electric Engagement Clutch for Threshing Cylinder Drive No. SLPT-D5	
		SN Sieve for Corn No. SLPT-C7			