

Low Profile Thresher

The SLPR is our most versatile thresher. It is preferred for duplicating results obtained with commercial combines; with a large capacity it is perfect for handling multiple crops including Cereals, Corn, Forages, Legumes, Sunflowers, and Small Grains. The Seedburo SLPR uses a metal raspbar cylinder and quick-adjust underslung concave (for easy feeding of bushy plant material) cylinder. Speed is adjusted via a single lever. Interchangeable cylinders are not needed. Design advantages include high capacity, easy interior inspection, and low machine height for safe, efficient operation from ground level. Ship dims: 122" (L) x 76" (W) x 67" (H), Ship wt: 2130 lbs, Export wt: 1730 lbs, Export dims: 98" (L) x 51" (W) x 62" (H).

Standard Equipped:

- Enclosed cylinder, 14" (D) x 17⁵/₈" (W) with 8 metal rasp bars
- Underslung, open-grated concave with single lever to adjust front and rear clearance
- Variable speed v-belt drive for threshing cylinder, speed range 300–1500 RPM
- Deflector-beater strawpuller
- Canvas deflector baffles
- Metal shaker pan
- Winninging pan with adjustable angle to control seed loss
- Clean grain chute with side exit
- Centrifugal fan winnowing blower with control shutter
- V-belt drives for low maintenance and quite operation
- Safety guards
- Screw type leveling jack and trailer hitch for 2" ball (50mm)
- Rubber cushion axle assembly, tapered roller bearings, 15" rims and radial tires
- Taillight assembly with stoplights, turn signals and rear reflectors



Please select a Base Model and one each from: Power Configurations, Sieve Configurations, Threshing Cylinder Feed Configurations, Threshing Cylinder Drive Configurations, Concave Configurations and Domestic or Export Required Packing.

Base Models	Power Configurations	Sieve Configurations	Threshing Cylinder Feed Configurations	Threshing Cylinder Drive Configurations	Concave Configurations	Required Packing
Gas and Electric No. SLPRGE	5HP, 220V/60Hz Electric Motor No. SLPR-A1	6mm Graepel Sieve (Grass) and Tailrake No. SLPR-E1	Feed Pan No. SLPR-B1	Standard Variable Speed Drive No. SLPR-C1	Standard Wire Spacing Concave No. SLPR-D1	Domestic Packing No. SLPR/DOM
Diesel Only No. SLPRD	5HP, 220V/50Hz Electric Motor No. SLPR-A2	10mm Graepel Sieve and Tailrake No. SLPR-E2	Belt Feed Conveyor No. SLPR-B2	Standard Variable Speed Drive and Cylinder Slow Down Drive No. SLPR-C2	Grass Wire Spacing Concave No. SLPR-D2	Export Packing Charges No. SLPR/EX
	8HP Honda Gas Engine w/ Elec. Start No. SLPR-A4	18mm Graepel Sieve and Tailrake No. SLPR-E3		Standard Variable Speed Drive and Electric Engagement Clutch No. SLPR-C3		
	8HP Honda Gas Engine w/ Elec. Start w/ High Amp Charger (For Use w/ Electric Accessories) No. SLPR-A5	20mm Graepel Sieve and Tailrake No. SLPR-E4		Cylinder Slow Down Variable Drive No. SLPR-C4		
	10HP Diesel Engine w/ Elec. Start No. SLPR-A7	22mm Graepel Sieve and Tailrake No. SLPR-E5				
		SN Sieve for Corn No. SLPR-E7				