

## Small Bundle Thresher

Ideal for threshing small sheaves of grain and other similar crops, the large feed housing and threshing cylinder increase efficiency without sacrificing sample purity. Cleaning pan is removable and comes with four interchangeable wire screens; 1/8", 1/4", 3/8" and 1/2" mesh. Cylinder and blower speeds are adjustable via interchangeable pulleys. Ship wt: 430 lbs, Ship dims: 42" (L) x 31" (W) x 49" (H), Export wt: 400 lbs, Export dims: 35" (L) x 33" (W) x 48" (H).



★ MADE IN  
★ USA  
SSBTGE

### Standard Equipped:

- Your choice of threshing cylinder, overshot style, with matching concave
- Feeding hopper
- Grain rebounding baffle
- Auxiliary beater and strawpuller
- Bladed type winnowing blower with adjustable air intake
- Removable recleaning pan
- Interchangeable screens for recleaning pan
- V-Pulleys and V-Belts
- Safety cover guard screens
- 10" x 1.75" ball bearing semi-pneumatic wheels
- Hand truck-type handles
- Grain catch pan

### Selection Guide For Each Cylinder/Concave Style

Cylinder/Concave	Crops
Square-spiked tooth (most aggressive)	Cereals, Oats, Rice, Wheat, etc.
Round-spiked tooth	Sorghum, Soybean
Metal raspbar	Grasses, Field Peas, Soybeans, Sunflower
Rubber-coated metal raspbar	Sorghum, Soybeans, Field Peas

Please select a Base Model and one each from: Power Configurations, Threshing Cylinder and Concave Configurations, Extra Cylinder, Extra Concave, Optional Accessories, Export Spare Parts Kit, and Domestic or Export Required Packing.

Base Models	Power Configurations	Threshing Cylinder and Concave Configurations	Extra Cylinders	Extra Concaves	Optional Accessories	Export Spare Parts Kits	Required Packing
Gas and Electric No. SSBTGE	1HP, 110V, 60Hz Electric Motor No. SSBT-A1	Round Spiked No. SSBT-B1	Rubber Raspbar (Inverted V-Belt) No. SSBT-C3A	Rubber Coated Metal Raspbars No. SSBT-C4A	Extra Seed Catch Pan No. SSBT-C1	Electric Model No. SSBT-SPKE	Domestic Packing No. SSBT/DOM
Diesel Engine No. SSBTD	1HP, 220V, 60Hz Electric Motor No. SSBT-A2	Square Spiked No. SSBT-B2	Rubber Coated Metal Raspbars No. SSBT-C3B	Square Spiked No. SSBT-C4B	Removable Sacking Chute No. SSBT-C2	Gas Model No. SSBT-SPKG	Export Packing Charges No. SSBT/EX
	3.5HP Briggs and Stratton Engine No. SSBT-A3	Rubber V-Belt Raspbar T.C. and Rubber Coated Steel Rasbar Concave No. SSBT-B3	Square Spiked No. SSBT-C3C	Round Spiked No. SSBT-C4C			
	4HP Honda Engine No. SSBT-A4	Rubber Coated Steel Raspbars No. SSBT-B4	Round Spiked No. SSBT-C3D	Rubber Raspbar Inverted-V No. SSBT-C4D			
	4.2HP Yanmar Diesel Engine No. SSBT-A5	Metal Raspbars No. SSBT-B5	Metal Raspbars No. SSBT-C3E	Metal Raspbars No. SSBT-C4E			
	1HP 220V 50Hz Electric Motor No. SSBT-A6						