

Single Plant Belt Thresher

The SSPBT is designed specifically for threshing single plants of Edible Beans, Soybeans, Sugar Beets, or other similar crops that have padded grains or heads of grains. It has adjustable clearance between the belts to regulate threshing aggressiveness. The air column cleaning system will help clean and keep seed samples pure. There is a feeding chute and side delivery seed collection chute. Ship wt: 730 lbs, Ship dims: 50" (L) x 34" (W) x 63" (H), Export wt: 660 lbs, Export dims: 50" (L) x 36" (W) x 64" (H).

Standard Equipped:

- 14" wide threshing belt
- Hinged safety cover guards
- Easily accessible start switch and safety kill switch
- Adjustable clearance between belts to regulate threshing aggressiveness
- Air column cleaning system for clean seed samples
- US standard size drive components and parts
- Quiet operations for indoor use
- Feeding tray directs crop into threshing area
- Side delivery seed collection chute
- Spring loaded door on seed chute to allow bagging small samples
- Spring loaded door can be locked in open position for continuous threshing
- Designed for use by single operator
- Trash containment curtain
- Clear plastic window installed in seed chute
- Electric models come with seed chute light



Please select a Base Model and one each from: Power Configurations, Belt Type, Frame Type, Optional Accessories, Upper Trash Deflector, and Domestic or Export Required Packing.

Base Models	Power Configurations	Belt Types	Frame Types	Optional Accessories	Upper Trash Deflectors	Required Packing
Electric Only No. SSPBTE	¾HP, 110V/60HZ Electric Motor No. SSPBT-A1	Upper and Lower Chevron No. SSPBT-B1	Axles with Tongue (Wheel Truck) No. SSPBT-C1	Root Cutter with Hand Grip on Thresher No. SSPBT-E1	Standard Trash Deflector No. SSPBT-D1	Domestic Packing No. SSPBT/DOM
Gas and Diesel No. SSPBTG	¾HP, 220V/60Hz Electric Motor No. SSPBT-A2	Upper and Lower Mini-Cleat Lock No. SSPBT-B2	Axle Lift Option for above No. SSPBT-C1A	Lighted Seed Chute (Standard On Elec. Units) No. SSPBT-E2	Trash Deflector with Window and Flipper No. SSPBT-D2	Export Packing Charges No. SSPBT/EX
	¾HP, 220V/50Hz Electric Motor No. SSPBT-A3	Upper and Lower Smooth No. SSPBT-B3	Stationary Stand (Elec. Models Only) No. SSPBT-C2	Seed Chute Extension for Feeding into Envelopes (One Included) No. SSPBT-E3	Threshing Plenum Adaptor with Window and Flipper No. SSPBT-D3	
	3HP, Air Cooled Gas Engine No. SSPBT-A4	Upper Smooth, Lower Chevron No. SSPBT-B4	Stationary Stand with Casters (Elec. Models Only) No. SSPBT-C3	Tag Holder No. SSPBT-E4		
	4.2HP, Air Cooled Diesel Engine No. SSPBT-A5	Upper Smooth, Lower Mini-Cleat Lock No. SSPBT-B5		Catch Bucket No. SSPBT-E5		
		Upper Chevron, Lower Mini-Cleat Lock No. SSPBT-B6				