

### Fischbein Portable Bag Closer

The rugged Fischbein Portable Bag Closer sews all kinds of paper, textile and poly bags dependably and stands up to the most demanding applications. This closer is simple to operate, even for inexperienced workers. Sews single thread type 101 chain stitch. The bag closer may be hand-held, mounted on a suspension unit, or on a Fischbein Carriage conveyor. An efficient internal oiling system lubricates all moving parts as the bag closer is operated. Housing is cast and machined to close tolerance.



It is available in 110V or 220V AC, or 12V DC versions. The unit is supplied with one package of needles, one cone of thread and operator's maintenance manual. Ship wt: 19 lbs, Ship dims: 15" (L) x 12" (W) x 15" (H).

- Fischbein Bag Closer, 110V, 50/60Hz.....No. MODEL F
- Fischbein Bag Closer, 220V, 50/60Hz..... No. MODEL F/A
- Fischbein Bag Closer, 12V DC Operation ..... No. MODEL F-12

### Bag Sewing Accessories

The Adjustable Reel-Type Suspension Balance holds the Model F Bag Closer within easy reach, relieving fatigue and protecting the closer from accidental damage. Ship wt: 7 lbs, Ship dims: 19" (L) x 13" (W) x 7" (H).



#### Bag Closer Suspension

Reel-Type Suspension Balance ..... No. 1550

#### Crepe Paper Tape (Carton of 10 Rolls, Approximately 1800 ft.)

Natural Kraft ..... No. D311N  
 White..... No. D311W

#### High Quality Thread, 65% Polyester / 35% Cotton Blend

8 oz Cones (for All Portable Models) (Each 8 oz Cone Will Sew Approximately 500 ft. Available in Cartons of 10 or 32 Cones)..... No. D305  
 2½ lb Cones..... No. D310  
 18 lb Jumbo Cones (For Belt Conveyor Models) ..... No. D318  
 Needles for D, E, and Model F Units (Package of 25) ..... No. DE5

#### Specialty Selected Lubricants (Use These to Insure Maximum Efficiency from Fischbein Bag Closing Equipment)

Cleaning Lubricant, 1 Gallon (for Cleaning Feed Mechanism Parts)..... No. D301  
*Quickly washes out all traces of abrasive and harmful dirt.*  
 Thread Lubricant, 1 Gallon..... No. D302  
*Required for closing waterproofed or specially processed, paper or textile bags. Saturates entire cone in seconds.*  
 Lubricating Oil, 1 Quart (for Lubricating All Parts) ..... No. D303  
*Lubricates properly under the most adverse sewing conditions. Flushes out abrasive dust and dirt accumulated on parts.*

### Fischbein Portable Bag Closer with Tape-Sewing Attachment

The Tape-Sewing Attachment allows the Model F closer to sew "stitch through tape" closures. The attachment uses 2" wide tape, which is available in the colors listed below. It includes closer, throat attachment, presser foot and tape attachment. Ship wt: 19 lbs, Ship dims: 15" (L) x 12" (W) x 15" (H).



- Fischbein Bag Closer, 110V, 50/60Hz.....No. MODEL F-T with Components for Tape Attachment.
- Fischbein Bag Closer, 220V, 50/60Hz..... No. MODEL F-T/A with Components for Tape Attachment.
- Replacement Tape Sewing Attachment..... No. 1650