



**Seedburo Tape Measures, Plumb Bobs and Measuring Wheel**

Seedburo Fiberglass Bin Tapes are designed to resist extreme weather conditions. Great to measure depth levels in storage bins and silos. Tape line is constructed of fiberglass and encapsulated in flexible "wipe-clean" plastic. Tape case and reel are made of high-impact polymer and double screws hold the housing together in the event of a drop. The crank handle is reinforced with metal to provide years of rugged use. The shovel handle is ideal for rapid reeling. Tape will not stretch, shrink or deteriorate. Printed in inches by 8ths or 10ths. Ship wt: 4 lbs, Ship dims: 15" (L) x 15" (W) x 5" (H).

Graduated in Inches by 1/8ths		1/10ths of a Foot by 1/100ths	
Model No.	Length	Model No.	Length
No. 508	50' Tape	No. 5010	50' Tape
No. 508R	50' Refill	No. 5010R	50' Refill
No. 1008	100' Tape	No. 10010	100' Tape
No. 1008R	100' Refill	No. 10010R	100' Refill
No. 2008	200' Tape	No. 20010	200' Tape
No. 2008R	200' Refill	No. 20010R	200' Refill
No. OTR50M	50m x 2mm	No. OTR100M	100m x 2mm
No. RF50M	50m Refill	No. RF100M	100m Refill

- 8 oz Spark-proof Brass Plumb Bob ..... **No. 939**
- Weighted, Spark-proof Sample Collecting Bob..... **No. 940**

**Measuring Wheel**



Seedburo's Measuring Wheel is built for durability and accuracy under tough field conditions. Ideal for fencing, nursery plot work and laying out irrigation systems. Each wheel is supplied with a 3-piece pistol grip handle and with quick-snap cam locks, the handle telescopes down to a compact 23". Easy-read magnified 5-digit counter measures 9,999 ft., 11 in. The metric unit measures a total of 9,999.9m. TM3 features 12 1/2" wheel diameter and 3 ft. wheel circumference. The TM3-M has a .318m wheel diameter with a 1m wheel circumference. The TM4 series features a 15 1/2" wheel diameter with a 4 ft. wheel circumference. The TM6.5 has a 25 1/4" wheel diameter with a 6 ft. wheel circumference. Ship wt: 6 lbs, Ship dims: 14" (L) x 8" (W) x 31" (H).

- Measuring Wheel with 5-Digit Reset Counter, in Feet and Inches ..... **No. TM3**
- Measuring Wheel with 5-Digit Reset Counter, in Meters ..... **No. TM3-M**
- Measuring Wheel with 5-Digit Reset Counter, in Feet and Inches ..... **No. TM4**
- Measuring Wheel with 5-Digit Reset Counter, in Feet and Inches ..... **No. TM6.5**

**Seedburo Tubular Steel Hook Ladders**



Seedburo's versatile "Hook Ladders" combine the strength of 3/4" x 18 Ga. tubular steel with 13 3/4" wide rungs welded-in, reinforced double side-rails and heavy duty hooks. These ladders have a 12" rise between rungs, feature a weatherproof, polyester powdercoat finish and non-slip rung design. Ladder is 14 3/4" wide, and the depth is 3" from the wall to the edge of the step. Each ladder has a 300 lb load capacity. Optional Rocker Type Safety Feet allow the Seedburo Steel Ladders to be used wherever straight ladders are used.

Available in lengths to 15 ft. This ladder provides easy access to permanently installed safety ladders when hooked onto the bottom rung. Model C Ladders are also good for truck, barge and bin applications. **All ladders ship via motor freight due to size and shape restrictions.**

Model No.	Length	Weight
No. C7	7 ft.	20 lbs
No. C10	10 ft.	30 lbs
No. C12	12 ft.	35 lbs
No. C15	15 ft.	44 lbs
Safety Feet - No. SF		