

BADGER RAIL CAR MOVERS

Badger Power-King



The Badger Power-King car mover is ideal for heavy car spotting where two or more heavily loaded cars must be moved at one time. Casting is made of malleable iron. The handle is select hickory and the pivotal connections are oversized to minimize wear. Hardened steel spurs grip the soft corners of the rail to prevent slipping. Ship wt: 23 lbs, Ship dims: 70" (L) x 5" (W) x 4" (H).

Badger Power-King Car Mover **No. 221B**

Badger Car Mover



The Badger Car Mover is used to move one car at a time and is recommended for use in yards where standard conditions prevail. The Badger Car Mover is based on the Compound-Leverage Principle and has a pinch-bar action for better control. Elongating toggle or cam provides the leverage and power to move loaded cars with ease. Ship wt: 22 lbs, Ship dims: 70" (L) x 5" (W) x 4" (H).

Badger Car Mover **No. 249**

Parts and Accessories for Car Movers



422

Badger Double Spurs, Per Pair, Ship wt: 1 lb, Ship dims: 9" (L) x 9" (W) x 7" (H) **No. 422**
 Safety Handguard, Fits on Part No. 420 Handle, Ship wt: 1 lb, Ship dims: 9" (L) x 7" (W) x 7" (H) **No. 421**
 Replacement Handle, Select Hickory, Ship wt: 8 lbs, Ship dims: 60" (L) x 5" (W) x 4" (H) **No. 420**

Seedburo "Super Chock"



An extra durable rail clamp designed to effectively block cranes, rail cars and mine cars during loading and unloading operations. Made to fit rails from 40 lbs to 175 lbs and all wheel diameters. Attachment is easy; the Super Chock locks itself to rail when wedge is driven home. Removal is just as easy. Unit is made of cast ductile iron. One rail clamp on each rail is recommended. Ship wt: 50 lbs, Please specify rail size when ordering. Net wt: 50 lbs, Actual dims: 17" (L) x 4" (W) x 12" (H), Ship wt: 53 lbs, Ship dims: 19" (L) x 13" (W) x 14" (H).

Super Wheel Chock for 60–104 lbs Rail **No. 4016-01**

Super Wheel Chock for 105–175 lbs Rail **No. 4016-02**

CAUTION: Rail wheel chocks are not to be used to stop a moving car. For land use only. Do not use to block cars on car ferries or barges.

Aldon Single Wheel Chock (28" Handles)



Net wt: 12 lbs, Actual dims: 31" (L) x 7½" (W) x 14" (H), Ship wt: 15 lbs, Ship dims: 35" (L) x 19" (W) x 9" (H).

Single Wheel Chock with Flag (Exposed Rail), Ship wt: 13 lbs **No. 4011-01**

Single Wheel Chock with Flag (Flush Rail), Ship wt: 13 lbs **No. 4011-02**

Aldon Double Wheel Chock (28" Handles)



Net wt: 20 lbs, Actual dims: 31" (L) x 9" (W) x 19" (H), Ship wt: 23 lbs, Ship dims: 35" (L) x 19" (W) x 9" (H).

Double Wheel Chock with Flag (Exposed Rail), Ship wt: 16 lbs **No. 4011-06**

Double Wheel Chock with Flag (Flush Rail), Ship wt: 16 lbs **No. 4011-07**

Safety Lights for Wheel Chocks



The lights have a 7" diameter lexan lens uses two 6V batteries. On-off switch and photo-electric cell flashes 60 times a minute, Battery case bolts to any sign holder or chock light bracket. **Safety Lights:** Net wt: 3 lbs, Actual dims: 15" (L) x 8" (W) x 4" (H), Ship wt: 5 lbs, Ship dims: 16" (L) x 9" (W) x 9" (H). **Carrying Bracket:** Net wt: 2 lbs, Actual dims: 8½" (L) x 4" (W) x 2¾" (H), Ship wt: 3 lbs, Ship dims: 9" (L) x 9" (W) x 7" (H). (Bracket bolts to any 1" diameter chock handle. Drill ¼" hole at bottom of handle. Chock safety Light bolts to bracket).

Flashing Red Light (Battery Operated), Ship wt: 5 lbs **No. 4115-17**

Flashing Blue Light (Battery Operated), Ship wt: 5 lbs **No. 4115-01**

Carrying Bracket for Light on Wheel Chock, Ship wt: 3 lbs **No. 4011-21**