



444

Humidity and Temperature Guides

Seedburo offers two durable, wall mount guides for determining relative humidity and temperature. The **No. 444** reads relative humidity only from 0 to 100% on a 3³/₄" diameter dial with black numerals in a silver chromium case. Our **No. 444T** reads relative humidity from 0 to 100% and temperature from 0 to 200°F and -20 to 100°C in 1° increments on a 4¹/₂" diameter dial with black numerals in a gold chromium case. Units are accurate to ±3% from 35 to 95%RH and can be easily recalibrated. Net wt: 12 oz, Ship wt: 2 lbs, Ship dims: 12" (L) x 3" (W) x 10" (H).

Humidity Guide.....	No. 444
Humidity and Temperature Guide	No. 444T

INSECTICIDE SPRAYERS



Dyna-Fog® Trailblazer Sprayer

The Trailblazer provides big machine performance in a compact; easy to handle package. This battery operated unit is designed to handle oil-based products. The high output of non-residual, thermal fog is great for both indoor and outdoor applications. The unit produces a "dry fog" and is ideally used to eliminate the flying insect, such as the Indian Meal Moth, found in a warehouse or barn. The unit uses six (6) "D" size batteries and has an electric start (batteries included). The removable, easy-to-clean tank has 1 gallon (3.8 liters) capacity. Output: 0-5 gallons/hour (0-19 liters/hour). Ship wt: 38 lbs, Ship dims: 32" (L) x 14" (W) x 21" (H).

Trailblazer Sprayer.....	No. TRLB
--------------------------	-----------------



Dyna-Fog® DC-3 Sprayer

The DC-3 Sprayer is an electric, portable aerosol applicator. A meter valve allows the operator to adjust the output. Three (3) precision nozzles combine to give a greater capacity. The durable body is constructed from a high-density polyethylene, chemical-resistant material. Designed to handle both water and petroleum based products, the DC-3 is capable of dispersing germicides and insecticides. Most commonly used with Malathion where a residue or "top dressing" on the grain or bin walls is desired. This application eliminates the crawling or nesting insect. Motor: 6.5 amps, 50/60Hz cycle, 20,000 RPM. Tank Capacity: 1 gal. (3.8 liters). Net wt: 6.6 lbs, Actual dims: 13" (L) x 8" (W) x 14" (H), Ship wt: 8 lbs, Ship dims: 15" (L) x 10" (W) x 18" (H).

DC-3 Sprayer, 110V	No. DF
--------------------------	---------------

Seedburo Insect Trap



Our insect trap early warning system lets you monitor insect activity in stored grain. This trap is made of tough, long-lasting perforated plastic and is 17" long. The tip is the reservoir for insect collection. The Seedburo trap can be used with or without pheromones or food attractants. For best results in 20 ft. diameter bins, place one probe in the center and one trap in each quadrant of the bin. Check traps within 24 hours of placement to detect crawling insects. If two or more of any insect species are caught in the first two hours, there is the potential of a treatable population. Traps sold in cartons of 3. Actual dims: 17" x 1¹/₄" dia., Net wt: 8 oz, Ship wt: 1 lb, Ship dims: 20" (L) x 8" (W) x 8" (H).

Insect Trap Kit with Three (3) Probes	No. TRAP1
---	------------------

Bird-X Bird Proof Repellent



Keep bird pests off their normal roosting areas with an application of Bird-Proof Bird Repellent, a non-toxic, sticky chemical that makes a surface tacky and uncomfortable to birds. It's non-toxic, and harmless to metal structures, sealed masonry and ornamental metals and lasts up to six months. Simply apply with a household type 10" caulking gun and you are done! It can be used in any type of weather, indoors, outdoors, virtually anywhere. Sold in cartons of 12, one carton treats 120 linear feet. EPA registered. Ship wt: 10 lbs, Ship dims: 12" (L) x 7" (W) x 5" (H).

Bird Proof Cartridges 12 Tube/Case.....	No. BIRDVIS-07
---	-----------------------