

SEEDBURO PLATED PROBES AND TRIERS

18" Nickel Plated Trier

Double-tube construction with 1/2" outside diameter and 5 openings 5/16" (W) x 1 3/4" (L). Open-handled. Net wt: 7 oz, Ship wt: 2 lb, Ship dims: 20" (L) x 4" (W) x 4" (H). **MADE IN USA.**



18" Nickel Plated Trier No. 235

30" Nickel Plated Trier

Double-tube construction with 1/2" outside diameter and 9 openings. 5/16" (W) x 1 3/4" (L). Open-handled or Partitioned versions. Net wt: 11 oz, Ship wt: 2 lbs, Ship dims: 32" (L) x 4" (W) x 4" (H). **MADE IN USA.**



30" Nickel Plated Trier No. 236

30" Partitioned Nickel Plated Trier No. 236-P

39" Chrome Plated Trier - 3 Long Openings

Double-tube construction, 7/8" outside diameter, 3 long openings, 8" (L) x 3/4" (W). Open-handled. Recommended for sampling cereal seeds with long straws present. Net wt: 2 lbs, Ship wt: 3 lbs, Ship dims: 43" (L) x 4" (W) x 4" (H). **MADE IN USA.**



39" Chrome Plated Trier No. 79A-OH

39" Chrome Plated Trier - 6 Openings

Double-tube construction with a 7/8" outside diameter and 6 openings 3/4" (W) x 2 1/2" (L). Open-Handled. Net wt: 2 1/2 lbs, Ship wt: 3 lbs, Ship dims: 43" (L) x 4" (W) x 4" (H). **MADE IN USA.**



39" Chrome Plated Trier No. 78-OH

Stainless Steel Sample Probes

Has 6 openings with the same structural design as the No. 78-OH (pictured above). Probe is designed for use with chemicals, corrosives, pharmaceuticals and fertilizers. Open-Handled Probe: Net wt: 2 1/2 lbs, Ship wt: 4 lbs, Ship dims: 45" (L) x 4" (W) x 4" (H). Partitioned Probe: Net wt: 3 lbs, Ship wt: 4 lbs, Ship dims: 45" (L) x 4" (W) x 4" (H). **MADE IN USA.**



Stainless Steel Open Handled Probe No. 65-OH

Stainless Steel Partitioned Probe No. 65-P

Auger-Tip Partitioned Probe

This brass partitioned probe has a wooden handle with two removable galvanized metal handles that form a 12" T-Handle below. It has 11 openings and an auger point to aid sampling wet or closely packed material. Net wt: 10 lbs, Ship wt: 11 lbs, Ship dims: 65" (L) x 4" (W) x 4" (H). **MADE IN USA.**



39" Auger-Tip Partitioned Probe No. 552

Ellis Sampler

This is used to obtain a sample from a moving belt conveyor or a falling stream of grain. Mouth dims: 6" (W) x 1" (D), Overall dims: 15" (L) x 8 1/2" (W), Net wt: 2 lbs, Ship wt: 4 lbs, Ship dims: 18" (L) x 12" (W) x 4" (H).

MADE IN USA.



Ellis Sampler No. 23

Go/No Go Gauge No. GNG

Special Truck Sampler

This sampler is used for catching samples of falling grain from trucks during unloading. To obtain a sample, cut through a falling stream of grain several times. Round steel container dims: 12" (L) x 4 1/2" (D), 2 qt. sample capacity. Complete with 36" wooden handle. Net wt: 5 lbs, Ship wt: 6 lbs, Ship dims: 45" (L) x 7" (W) x 7" (H). **MADE IN USA.**



Seedburo Special Truck Sampler No. 525

Pelican Grain Sampler

Used for obtaining sample from a falling stream of bulk grain. Pouch is approximately 18" (L) x 6" (D) x 2" (W) made of russet top grade cowhide hand riveted to the frame. Meets USDA specifications. Net wt: 3 lbs, Ship wt: 5 lbs, Ship dims: 19" (L) x 13" (W) x 6" (H). **MADE IN USA.**



Pelican Grain Sampler (Without Handle) No. 24

Seedburo Level Yoke

The Seedburo Lever Yoke uses an interlocking fulcrum principle to wrap around the outside of any probe with 1 3/8" diameter, forming a T-handle. Each handle is 17" long and has a hand grip. Net wt: 10 lbs, Ship wt: 11 lbs, Ship dims: 21" (L) x 15" (W) x 11" (H). **MADE IN USA.**



Seedburo Lever Yoke No. 90

Replacement Pads for Lever Yoke No. 90-RP