

**SEEDBURO BIN PROBES AND THERMOMETERS**

**Thermo Sampler**

Brass thermo sampler combines the function of a bin thermometer and a deep bin cup. Operates like the Deep Bin Cups in extracting a sample, with the exception of the added twist-off tip enclosing a spirit-filled thermometer. Extension rods and T-handle required. Net wt: 2 lbs, Ship wt: 3 lbs, Ship dims: 20" (L) x 8" (W) x 8" (H). **MADE IN USA.**

372



- Thermo Sampler, 200 gram Capacity for Corn, -15 to 120°F.....**No. 372**
- Thermo Sampler, -20 to 220°F (-10 to 110°C).....**No. 372D**
- Refill Thermometer, -15 to 120°F .....**No. 212R**
- Dual Range Refill Thermometer, -20 to 220°F (0 to 110°C).....**No. 212DR**
- Carrying Case (Holds Up to 15 Extensions w/ T-handle and Sampler)... **No. 372DB**

**Deep Bin Cups**

These brass cups can be used with only 4 ft. of headroom at the top of your bin. The cup remains closed as long as the probe is being pushed down. Opens when probe is being pulled out. It is available in two sizes, 12" and 15". Both sizes have an outside diameter of 1½". Extension rods and T-handle required. Net wt: 1 lb, Ship wt: 2 lbs, Ship dims: 12" (L) x 9" (W) x 5" (H). **MADE IN USA.**

233



- 12" Deep Bin Cup (185 gram Capacity for Corn).....**No. 233**
- 15" Deep Bin Cup (265 gram Capacity for Corn).....**No. 234**

**Special Bin Thermometers**

An 8¼" solid brass cover encases a 5⅜" glass spirit-filled thermometer protected by a plastic cover. The unit takes grain temperatures in bins. Three temperature ranges available. Attaches to standard 3 ft. extensions and T-handle. Net wt: 1 lb, Ship wt: 2 lbs, Ship dims: 12" (L) x 9" (W) x 5" (H). **MADE IN USA.**

213



- Special Bin Thermometer, -15 to 120°F, 2° Divisions.....**No. 213**
- Special Bin Thermometer, -20 to 220°F, 2° Divisions.....**No. 213H**
- Dual Range Bin Thermometer, -20 to 220°F (0 to 110°C), 2° Divisions...**No. 213D**
- Refill Thermometer, -15 to 120°F .....**No. 212R**
- Refill Thermometer, -20 to 220°F .....**No. 212HR**
- Refill Thermometer, -20 to 120°F (0 to 110°C).....**No. 212DR**

**Extension and T-Handle**



- 3-Foot Extensions.....**No. STD-3**
- T-Handle ..... **No. STD-T**
- Carrying Case.....**No. 372DB**

**Seedbuero Grip Handled Bag Triers**

Grip-handled Bag Triers from Seedbuero are ideal for obtaining samples from bags for all varieties of seeds and grains. Made of Stainless steel with a molded grip handle for sure-handed sampling, these triers are available in three sizes. See below for specifications. Net wt: 1 lb, Ship wt: 2 lbs, Ship dims: 12" (L) x 9" (W) x 3" (H).



- Peanut Bag Trier SS with Sheath 18½" x 1⅜" .....**No. TRIER-1**
- Sunflower Seed Bag Trier SS with Sheath 18⅛" x 1¼" .....**No. TRIER-2**
- Corn Bag Trier SS with Sheath 7½" x 1⅛" .....**No. TRIER-3**

**Seedbuero Nobbe Triers**

The Nobbe type seed trier is used for sampling free-flowing, small seeded crops in bags or penetrable containers. It is ideal for clovers, timothy, brassicas, fine grasses such as bluegrass, and small vegetable seeds. It is inserted horizontally into the seed bag and the sample pours out of the open end. Seedbuero's Nobbe trier available in a ½" or ¾" diameter version; Options for either 20" or 30" overall length. The one opening starts 2⅜" from the tip and is 2½" long. Available in Brass or Stainless Steel. Ship wt: 1 lb, Ship dims: 21" (L) x 4" (W) x 4" (H). **MADE IN USA.**



- Brass Nobbe Trier ¾" OD x 20" Single Tube w/ 1 Opening.....**No. 223**
- Stainless Steel Nobbe Tier ¾" OD x 20" Single Tube w/ 1 Opening ..**No. 223S**
- Stainless Steel Nobbe Tier ¾" OD x 30" Single Tube w/ 1 Opening..**No. 223S-30**
- Brass Nobbe Trier ½" OD x 20" Single Tube w/ 1 Opening.....**No. 222**
- Stainless Steel Nobbe Trier ½" OD x 20" Single Tube w/ 1 Opening..**No. 222S**