

Seedburo No. 2 Miller

The Seedburo No. 2 Miller tests Rice samples for milling quality, grading, color and style. This miller can provide reliable results similar to the No. 3 Seedburo Miller. Designed primarily for the Rice buyer as a guide. It is not intended to replace the No. 3 Miller as a grading machine. Sample size approximately 160g. The miller is available with an integrated digital timer or without timer. Equipped with 1/3HP, 1 PH motor. Net wt: 45 lbs, Ship wt: 68 lbs, Ship dims: 19" (L) x 12" (W) x 20" (H).

- Miller, 115V, 60Hz, without Timer No. 60-115-60-2
- Miller, 230V, 60Hz, without Timer No. 60-230-60-2
- Miller, 110V, 50Hz, without Timer No. 60-110-50-2
- Miller, 220V, 50Hz, without Timer No. 60-220-50-2
- Miller, 115V, 60Hz, with Digital Timer No. 60-115-60-DT
- Miller, 230V, 60Hz, with Digital Timer No. 60-230-60-DT
- Miller, 220V, 50hz, with Digital Timer No. 60-220-50-DT
- Complete Basket Assembly No. 60CRMB
Includes: 60BCOKIT, 60KNKIT, and 60PCAKIT
- Basket Components Only, Assembled No. 60BCOKIT
Includes: end plug, 6 bolts, front/rear end plates, 10 guide pins, 2 space bar, screen, lever holder space bar
- Stainless Steel Pressure Cover No. 60-01-OS
- End Plug No. 60-02-00
- Front End Plug No. 60-04-00



★ MADE IN USA

No. 2 miller with digital timer, optional external digital timer available

- Clean Out Brush No. 60-45-00
- Replacement Cylinder No. 60-07-00
- Replacement Standard Screen, 3/64" No. 60-09-00
- Rear End Plate No. 60-11-00
- Adapter Shaft No. 60-14-56
- External Digital Timer, 115V, 60Hz No. 60EDT16
- Required Crating, Wooden Box No. 60/DOM

Seedburo No. 3 Miller

This miller accurately tests Rice samples for milling yield by automatically controlling both the milling pressure and the time cycle. Milling pressure is controlled with iron weights in increments of 1/2 lb up to 10 lbs for a wide range of milling results. An automatic digital timer stops the machine at the desired interval. A manual red push button "stop" control is also installed at the control panel box.

All the interior surfaces in contact with the Rice are hard chrome-plated, rust-free and long wearing. This sturdy machine is built to comply with the service requirements of the USDA Federal/State Rice Inspection Service. Sample size approximately 1000g.

Equipped with 3HP motor, standard wiring, 220V, 60Hz. 3 phase, complete with automatic digital timer and starter. All wires connected and tested, ready for installation and connection to power source. Net wt: 250 lbs, Ship wt: 275 lbs, Ship dims: 35" (L) x 21" (W) x 30" (H).

- Miller, 220V, 60Hz, 3Ph No. 65-220-60-3
- Miller, 220V, 50Hz, 3Ph No. 65-220-50-3
- Replacement Cylinder No. 650100
- Replacement Standard Screen No. 651700
- Stainless Steel Pressure Cover No. 652400
- Required Crating, Wooden Box No. 65/DOM
- Clean Out Brush No. 60-45-00



★ MADE IN USA

No. 3 Rice Miller