



2293 S MT PROSPECT RD
DES PLAINES, IL 60018
TOLL FREE: 800-284-5779
PHONE: 312-738-3700
FAX: 312-738-5329

BURROWS MODEL DMC500 PORTABLE MOISTURE TESTER



The Burrows Model DMC500 Digital Moisture Tester is versatile, compact and rugged for all types of field use. You no longer have to refer to charts, dials or manual temperature readings while in the field. Simply select the type of grain to be tested with the right or left arrow keys on the touch panel. Next weigh and balance your sample in the cup provided, dump the sample in the hopper and press the load button. The Model DMC500 automatically corrects for temperature and

displays the moisture percentage and the temperature. Moisture range is from 5 to 40% depending upon the commodity. Standard grains that can be tested are barley, beans, cocoa, coffee, corn, flax, millet, oats, peanuts, popcorn, rapeseed, paddy and white rice, rye, safflower, sorghum, soybean, sunflower and wheat. Operating temperature is 5 to 40°C.

The Model DMC500 operates with a 9V battery (not included) or AC/DC converted that is supplied with the tester and operates from 100V to 240V, 50/60HZ, 1PH. The unit can display results in English, French, Spanish or Portuguese at the users discretion. Net wt. 9 lbs., Ship wt. 11 lbs. Actual dims. 10"L X 7"W X 13"H, Ship dims. 13"L X 10"W X 18"H.

Burrows Model 500 Portable Moisture Tester No.DMC500
Replacement AC/DC Converter No.DMC500ACDC