


doron®



APS 7000XL
All Purpose Scale

- *Washdown Safe Stainless Steel Construction*
- *Incorporates Advanced Features*
- *Zero, Units and Print Pushbuttons Built In At No Extra Cost*
- *Resolution...1:3000 or 1:5000*
- *USDA Approved*



The new Doran APS7000XL is a series of all purpose scales that combine the advanced features and ease of use of the 7000XL Series Scales with the durability and ruggedness of our time proven DSP Scale Platforms. A remarkable value, the APS7000XL is ideally suited for a wide variety of weighing tasks. Capacity up to 1000 lb and platform sizes up to four square feet, it's your best choice for heavy duty weighing use.

RUGGEDLY BUILT...

Featuring 304 stainless steel construction and a water resistant design like all Doran Scales, the APS7000XL gives you a versatile and dependable general purpose scale ideal for use in food processing, manufacturing, and shipping applications, to mention just a few! The column mounted indicator provides clear, concise weight readings and a tough mylar touch panel which incorporates not only push-button ZERO, but also UNITS & PRINT features at no extra cost!



APS7000XL/18S, 18" x 18" Platform

WASHDOWN SAFE...

The XL touch panel uses Doran's new, exclusive "Picture Frame" sealing technique to ward off the damaging effects of water washdown. Rubber gaskets protect the sensitive electronics inside. All models are USDA approved.

INSTALLS ANYWHERE...

The readout is mounted on an adjustable column that can be set to varying heights, thereby permitting the scale to be mounted on a bench or floor as your job requires. Or, the column can be removed and the indicator can be mounted on a flat surface for even greater flexibility. Choose from platform sizes of 12" x 16", 18" x 18", 18" x 24" or 24" x 24" and capacities from 60 to 1000 lb!

USER PROGRAMMABLE...

Some of the user friendly menu setup features include:

Display Units: lb, kg, oz, grams, lb & oz

Auto Zero Tracking: off, 1/2, 1 or 3 div.

Update Rate: 1 to 10 readings/second

Serial Data Format: Auto-transmit I, II demand, or continuous RS-232

Motion Band: 1, 3 or 5 divisions

EASY SETUP AND CALIBRATION...

Factory calibrated and ready to use, the XL Series Scales are a snap to install. For periodic calibration, the service technician can choose from 1/4, 1/2 or full capacity - a real help in the field. The XL offers Standard (3000 d) and Precision (5000d) resolutions with a rock-solid display enhanced by Doran's exclusive hardware and software filters developed over many years of making reliable scales!

**APS 7000XL
All Purpose Scale**



7000XLM Indicator

FOR BASIC WEIGHING...

The new XL Scales electronic weight indicator is fast and easy to use. Just press the oversized ZERO button to tare a container and you're ready to get net weights in less than a second. Press UNITS to select the weight display - lb, kg, oz, g or lb & oz are available. The PRINT button allows data to be sent to external devices like printers or PC's. Many more selectable features are set via the user menu to customize the XL to your application.

OPTIONS...

- RS-232 Serial Output
- 4 to 20 ma Analog Interface
- Remote Zero, Units or Print Pushbutton
- Cable Disconnect (Load cell or Serial)
- 230 VAC Operation

WARRANTY...

Two years on parts and labor. Specifications subject to change without notice.

DORAN 7000XL SELECTION CHART

Cap. (lb)	Resolution**		Scale Platform Size			
	Std	Prec	12" x 16"	18" x 18"	18" x 24"	24" x 24"
60	x.02	x.01	APS7060XL	APS7060XL/18S	APS7060XL/1824	APS7060XL/2424
150	x.05	x.02	APS7150XL	APS7150XL/18S	APS7150XL/1824	APS7150XL/2424
300	x.1	x.05	APS7200XL*	APS7300XL/18S	APS7300XL/1824	APS7300XL/2424
500	x.2	x.1	-	-	APS7500XL/1824	APS7500XL/2424
1000	x.5	x.2	-	-	APS71000XL/1824	APS71000XL/2424

*200 lb capacity **Add "S" suffix for Standard, "P" for Precision Resolution



2293 S Mt. Prospect Road
Des Plaines IL 60018 USA
PH: 312-738-3700 or
800-284-5779
FAX: 312-738-5329

E-Mail: sales@seedburo.com
Web: www.seedburo.com